




Part List of Electric Sprayer

No.		Qty.
1	Top enclosure	1
2	Motor assembly	1
3	Motor ring	1
4	Motor inner cover	1
5	Inlet filter	1
6	Motor outer cover	1
7	Strap roller	2
8	Switch	1
9	Bottom enclosure	1
10	Gun bottom	1
11	Gun set	1
12	O ring	2
13	Foot pad	7
14	cord bushing	1
15	Cord guard	1
16	Screw	2
17	Powe cord	1
18	Air hose connector 2#	1
19	Air hose	1
20	Air hose connector 1#	1
21	Motor cover	1

22	X2 Capacitor	1
23	Air outlet connector	1
24	Screw	8