




Exploded View for S1Z-DW04-58

39	Adjustment knob	1
38	Screw	4
37	Index	1
36	Upper Housing	1
35	Inner Right Housing	1
34	Screw	4
33	Cap Ring	1
32	Screws	4
31	Adjustment	1
30	Washer	1
29	Grinding Wheel	1
28	Wheel Base	1
27	Spring	1
26	Capacitor	1
25	Terminal	1
24	Lower Housing	1
23	Cable Plate	1
22	Cable Cover	1
21	Cable	1
20	Screw	2
19	Rubber pad	4
18	Screw	4
17	Switch	1
16	Motor	1
15	Gear Case Cover	1
14	Small washer	2
13	Screw	2
12	Gear Plate	1
11	Gear	1
10	Gear Cage	1
9	Planet Gear	6
8	Gear Shaft	1
7	Gear Case	1
6	Oil Bearing	1
5	Steel ball	14
4	Ball Washer	1
3	Check Ring	1
2	Screw	2
1	Inner Left Housing	1
Part No	Description	Qty